

Maintenance and Housekeeping Procedures

Top & Sink Cleaning Instructions

After installation is completed, wipe down epoxy resin countertops and sinks, using #0000 steel wool or Scotchbrite® grey pad, with Simple Green® or Epoxy Resin Finishing Oil. Do not use steel wool or the grey pad on epoxy resin countertops or sinks without one of the liquids. Use this same procedure whenever any general cleaning is to be done.

Preventative Maintenance

1. Do not wax epoxy resin countertops or sinks.
2. Promptly remove all spills to ensure a safe working environment.
3. Polish epoxy resin countertops regularly, following cleaning procedures outlined above.
4. Although epoxy resin is the “material of choice” for countertops and sinks in the harsh chemical environment of laboratories, it is subject to Thermal Shock, and is not warranted against damage from liquid nitrogen or dry ice. Abuse from these materials could cause cracking and sink failure.